



## Kawasaki TERYX<sup>®</sup> H2 Cubby Mount for PCI Race Radios Trax Plus Intercom



Required Tools	
Drill	1" Drill/Step Bit

Parts Included	
Self-Tapping Phillips Screw (4)	

### Installation:

1. Drill a 1" hole into the cubby. Run the Intercom harnesses into the cubby.



2. Mount the PCI Trax Intercom to the Cubby Mount using their supplied screws.



3. Connect the PCI Trax Intercom harnesses.

4. Mount the Cubby Mount to the vehicle using the supplied Self-Tapping Phillips Screws (4) and a drill. Put the **drill motor to the lowest torque setting** and screw the mount to the dash.

