



Kawasaki TERYX® H2 Cubby Mount for Rugged Radios STX Intercom



Required Tools	
Drill	1" Drill/Step Bit

Parts Included	
Self-Tapping Phillips Screw (4)	

Installation:

1. Drill a 1" hole into the cubby. Run the Intercom harnesses into the cubby.



2. Mount the Rugged Radios STX Intercom to the Cubby Mount using their supplied screws.



3. Connect the Rugged Radios STX Intercom harnesses.

4. Mount the Cubby Mount to the vehicle using the supplied Self-Tapping Phillips Screws (4) and a drill. Put the **drill motor to the lowest torque setting** and screw the mount to the dash.

